

User manual

Remember: always start & stop charging session using the same method.

1. Connect the selected plug to your car.
2. Make sure that the cable is plugged into the socket correctly.
3. To start a charging session, scan the QR code above the connector or hold your RFID card over the reader
4. The QR code will direct you to Charge Assist app, you do not need to create an account, if you already have the application, charging will start automatically.
5. To stop, click "Stop" in the app or hold your RFID card over the reader again.

The charging price is listed in the Charge Assist app and on the charging station screen. If you use a RFID card from another operator, the charging price will be shown in their system.

Remember to leave the parking lot after charging is finished.

In case of any problems related to the charging process or detected irregularities in the charging station, please contact us. We make every effort to provide you with the highest quality services.



(+48)221042777



support@powerdot.pl

Instrukcja obsługi

Pamiętaj: zawsze kończ ładowanie tą samą metodą którą rozpocząłeś.

1. Podłącz wybrany przewód do samochodu.
2. Upewnij się, że kabel został włożony do gniazda poprawnie.
3. Aby rozpocząć ładowanie zeskanuj kod QR znajdujący się nad złączem bądź przyłóż kartę RFID do czytnika.
4. Kod QR przekieruje Cię do Charge Assist, nie musisz zakładać konta, jeżeli już miałeś aplikację, to rozpocznie się ładowanie.
5. Aby zakończyć ładowanie kliknij “zatrzymaj” w aplikacji lub ponownie zbliż kartę do czytnika.

Cena za ładowanie jest podana w aplikacji Charge Assist lub na ekranie stacji ładowania. Jeżeli korzystałeś z karty RFID innego operatora cena podana jest w jego systemie.

Pamiętaj o opuszczeniu miejsca parkingowego po zakończeniu ładowania.

W przypadku problemów związanych z ładowaniem lub wykrytymi nieprawidłowościami dotyczącymi stacji ładowania bardzo prosimy o kontakt. Dokładamy wszelkich starań aby świadczyć Państwu usługi najwyższej jakości.



+48 123 456 789



support@powerdot.pl